

Drop-In Seat

SKU: 29012

Page: 1 of 1



1. These are gunwale friendly. The broad vinyl ends spreads the weight out to not cause harm to your gunwales.
2. Adjust to the taper of your canoe, with the lip to the outside so it cannot fall off.
3. There are two telescoping ranges available – 32” to 36” and a wider model that adjusts to 38”.
4. Clamps are used to hold the seat in place while canoeing, storing and portaging. The carriage bolts need to be set into the pre-drilled holes on the outside of the black plastic hangers. Set with a couple firm taps from a hammer. The black plastic knobs go to the inside of your boat and should be tightened securely.

